

# Bushnell®

## SPORTVIEW®

### 20-60 x 60mm Vari-Power Spotting Scope

#### 1. MOUNTING

Remove the spotting scope and tripod from the box. Screw the tripod attachment screw into the tripod boss on the spotting scope. Spread the tripod legs and set on a solid surface.

#### 2. CONTROLS

The spotting scope is focused with the focus ring. The tube with the vari-power ring and the eyepiece will move "in" and "out" depending on the direction the ring is turned. When the tube is all the way "out," the spotting scope is at its closest focus position.

The magnification is changed by rotating the vari-power ring. It will be necessary to re-focus when the magnification is changed.

The spotting scope is positioned, on the tripod with the elevation and horizontal control. To adjust where the scope is pointing, rotate the handle counter clockwise. To lock, rotate the handle clockwise.

#### 3. USE

Remove the dust caps. Point the spotting scope as desired – as described in section 2.

**CAUTION: DO NOT LOOK AT THE SUN THROUGH THIS SPOTTING SCOPE AS SEVERE EYE DAMAGE MAY RESULT.**

Set the vari-power ring at the lowest power (20x). Focus the spotting scope as described in section 2. Increase the power, and re-focus. Please note, however, that at the highest powers the image may not appear sharp, because of several causes. First, the image will become less bright, second, all disturbances and contaminations in the air will be emphasized, and last, all motion and vibration of the spotting scope and support will also be magnified.

#### 4. CARE

The lenses of your spotting scope are 100% hard magnesium fluoride coated for highest light transmission. As with any optical coating, special care must be taken in cleaning the lenses. A Lens Cleaning Kit is recommended. Moisten surface of lens slightly and wipe dry using a circular motion starting at center of lens. Wipe or brush off any dirt or dust on the outside of spotting scope and tripod.



Model # 78-2061

#### 5. CAUTION

Never disassemble your spotting scope or tripod. Special tools and equipment are required for service and irreparable damage can result from untrained attempted service. Unauthorized service may also void the Warranty.

### WARRANTY/REPAIR

#### SPOTTING SCOPE LIFETIME LIMITED WARRANTY

Your spotting scope is warranted to be free of defects in materials and workmanship for the lifetime of the original owner. The Lifetime Limited Warranty is an expression of our confidence in the materials and mechanical workmanship of our products and is your assurance of a lifetime of dependable service. In the event of a defect under this warranty, we will, at our option, repair or replace the product, provided that you return the product postage prepaid. This warranty does not cover damages caused by misuse or improper handling, installation or maintenance of the product.

Any return made under this warranty must be accompanied by the items listed below:

- 1) A check in the amount of \$10.00 to cover the cost of handling
- 2) Name and address for product return
- 3) An explanation of the defect
- 4) Product should be well packed in a sturdy outside shipping carton to prevent damage in transit and return postage prepaid to the address listed below:

**IN U.S.A. Send To:**

Bushnell Performance Optics  
8500 Marshall Drive  
Lenexa, Kansas 66214

**IN CANADA Send To:**

Bushnell Performance Optics  
25A East Pearce Street, Unit 1  
Richmond Hill, Ontario L4B 2M9

For products purchased outside the United States and Canada please contact your local dealer for applicable warranty information. This warranty gives you specific legal rights. You may have other rights which vary from country to country.